



For correct installation of the SafeSeal suspension tool, please follow the following procedure.

For closing the cable ties, we recommend the manual processing tool with metal housing type MK6, up to a tie width of 9 mm, from manufacturer HellermannTyton.

However, also commercially available cable tie tools can be used, suitably for tie width of 7mm.

1



2



3



Step 1-3:

Insert the SafeSeal closure trough the opening of the suspension and fold the film around it.

4



5



6



Step 4:

Tying the cable tie around the film.

Step 5:

Use the tool to tighten the cable tie.

Step 6:

Put on the protective cover on the interface of the cable tie.